

Switch Operation

User input 'clicks' must be performed within 1 Second of each other. If your MAG-TAC® appears to go dim immediately after turning it ON, it means your battery is almost dead. Charge it.

Notes:

DO NOT attempt to use any battery other than the one provided with your MAGLITE®.

Make sure your light is Turned OFF before inserting it into the charging cradle.

When not in use, your MAG-TAC® Flashlight should be turned OFF and left in the charging cradle.

MAG-TAC® LED RECHARGEABLE - FUNCTIONS	
User Input	Mode
1 CLICK (hold)	1-Momentary ON
2 CLICKS	2-Latch ON
3 CLICKS	3-Power Save
4 CLICKS	4-Strobe

