

OPERATION: Install Batteries with the “+” end facing the head end of the flashlight. Backwards installation can damage the LED. Multi-Mode Electronic Switch selects four different operating modes as follows: Turn flashlight on once (by twisting the head) and you have Full (100%) Power Mode. Quickly turn flashlight off and on again to access Power-Conserving (25% Power) Mode; again for Blink Mode; again for SOS Mode. Turn the flashlight off and on again and you’re back to Full Power Mode. Focus the Beam simply by rotating head. Candle Mode - Unscrew head to detach. Invert head and place tail end of flashlight into the inverted head. Flashlight will act as a candle.

