

OPERATION: Large end of battery spring must be snapped into tailcap. Install batteries with the “+” end facing the head end of the flashlight. Backwards installation can damage the LED. Turn flashlight on and off by twisting the head. Rotate the head to focus the beam. Candle Mode – unscrew the head to detach. Invert head and place tail end of the flashlight into the inverted head. Flashlight will act as a candle.

