

OPERATION: Large end of battery spring must be snapped into tailcap. Install Batteries with the “+” end facing the head end of the flashlight. Switch -- For “On,” press switch button down until it clicks; click again to turn off. For momentary (silent signal) operation, press switch button halfway down and hold. Flashlight stays on only until button is released. Focus the Beam from spot to flood by rotating the head. Changing the lamp -- Find spare lamp in tail cap. Unscrew head assembly and gently pull old lamp straight out of the socket. Make sure new lamp’s pins are straight; insert into socket.